

INSTALLATION INSTRUCTIONS

Conical coupling

Edition 2017/08

- 1.) File the end of each cable to avoid sharp edges, which could damage the collet [3].
- 2.) Note: the cable should not be oxidized in the clamping part, because this could lead to a local heat development. Oxidized cables should be cleaned with a wire brush.
- 3.) Insert cable until it makes contact with the washer [4]. The wire end must be visible through the window [6].
- 4.) Tighten the cable so, that the collet [3] is pulled into the conical sleeve [2] and the necessary clamping force is created.
- 5.) A conical coupling mounted in this correct way, will hold the cable until its breaking load.

